

DigiNip-2 Sensor Check

Verification Clamp, DigiCheck for DigiNip-2 The clamp is calibrated for a measurement of : - 5 mm +/- 4

The DigiNip-2 nips have a tolerance of +/- 10%. Measurements should therefore be between : - 4.5 mm to 5.5 mm



How do I use the checking clamp?

- 1 - Position the nip as perpendicularly as possible as shown in the photo opposite.
- 2 - The rubbers must be in the centre of the measurement area
- 3 - Close the clamp.
- 4 - Apply constant pressure.

